- AMF0 , AMF3 인코딩 과정과 Red5 소스 분석

http://www.onnuristream.com 2016.01.26



#### **CONTENTS**


- 1. Chunk format
- 2. RTMP Packet Header
- 3. Example) CreateStream
- 4. Invoke Message Structure
- 5. Ping Message Structure
- 6. Server Bw/Client Bw Message Structure
- 7. Set Chunk Size
- 8. AMF0 data types
- 9. Example) AMF0
- 10. Red5 encode string sequence diagram
- 11. Red5 AMF Output class diagram
- 12. Red5 AMF3 Output class diagram
- 13. 참고 자료



### **RTMP Chunk Stream**

#### > Chunk Format

# Each chunk consists of a **header** and **data**. The header itself has three parts:



Chunk Format

max header size: 18 bytes

Wikipedia 에서 말하는 full header size: 12 bytes

Basic Header (1 to 3 bytes)
Message Header (0,3,7, o 11 bytes)
Extended Timestamp (0 or 4 bytes)
Chunk Data (variable size)

#### > Basic Header

0 1 2 3 4 5 6 7


(3byte 까지 확장 가능) - cs id: Chunk Stream ID

Chunk basic header 3

0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3

#### > Chunk Message Header

Type 0 chunk headers are 11 bytes long Type 1 chunk headers are 7 bytes long Type 2 chunk headers are 3 bytes long. Type 3 chunks have no message header.



Chunk Message Header - Type 2




#### **RTMP Chunk Stream**

#### Maximum Header size

```
red5-server-common\...\rtmp\codec\RTMPProtocolEncoder.java
                                                                      max header size: 18 bytes
                                                                      Wikipedia 에서 말하는 full header size: 12 bytes
        /**
116⊖
117
         * Encode packet.
118
                                                                      Basic Header (1) to 3 bytes)
          * @param packet
                              RTMP packet
119
                                                                      Message Header (0,3,7, or 11 bytes)
          * @return
120
                              Encoded data
121
                                                                      Extended Timestamp (0 or 4 bytes)
122⊖
        public IoBuffer encodePacket(Packet packet) {
                                                                      Chunk Data (variable size)
123
            IoBuffer out = null;
124
            final Header header = packet.getHeader();
125
            final int channelId = header.getChannelId();
             log.trace("Channel id: {}", channelId);
126
            final IRTMPEvent message = packet.getMessage();
127
128
            if (message instanceof ChunkSize) {
129
                ChunkSize chunkSizeMsg = (ChunkSize) message;
130
                 ((RTMPConnection) Red5.getConnectionLocal()).getState().setWriteChunkSize(chunkSizeMsg.getSize());
131
            // normally the message is expected not to be dropped
132
133
            if (!dropMessage(channelId, message)) {
134
                IoBuffer data = encodeMessage(header, message);
135
                if (data != null) {
136
                    RTMP rtmp = ((RTMPConnection) Red5.getConnectionLocal()).getState();
                    if (data.position() != 0) {
137
138
                        data.flip();
139
                    } else {
                        data.rewind();
140
141
142
                    int dataLen = data.limit();
143
                    header.setSize(dataLen);
144
                    // get last header
145
                    Header lastHeader = rtmp.getLastWriteHeader(channelId);
146
                    // maximum header size with extended timestamp (Chunk message header type 0 with 11 byte)
                    int headerSize = 18;
147
                    // set last write header
148
                    rtmp.setLastWriteHeader(channelId, header);
149
                    // set last write packet
150
                    rtmp.setLastWritePacket(channelId, packet);
151
152
                    int chunkSize = rtmp.getWriteChunkSize();
                    // maximum chunk header size with extended timestamp
153
154
                    int chunkHeaderSize = 7;
155
                    int numChunks = (int) Math.ceil(dataLen / (float) chunkSize);
156
                    int bufSize = dataLen + headerSize + (numChunks > 0 ? (numChunks - 1) * chunkHeaderSize : 0);
```



> RTMP Packet Header




#### Basic Header

- \* 2 bit : Chuck type (fmt)
- 00 : full header
- 01 : 8 bytes like type b00. not including message ID (4 last bytes).
- 11: Basic Header 만 가지고 있다.
- 10 : Basic Header 와 timestamp 까지만 가지고 있다.
- \* 6 bit : stream ID
- 1: extended stream ID 라는 뜻이어서 뒤따라오는 2 byte 가 stream ID 가 된다.
- 2 : Ping 이나, Set Client Bandwidth 메시지같은 low level message 라는 것을 의미한다.



101


> RTMP Packet Header - Basic Header



If the value of the remaining 6 bits of the *Basic Header* (BH) (least significant) is 0 then the BH is of 2 bytes and represents from Stream ID 64 to 319 (64+255); if the value is 1, then the BH is of 3 bytes (last 2 bytes encoded as 16bit Little Endian) and represents from Stream ID 64 to 65599 (64+65535); if the value is 2, then BH is of 1 byte and is reserved for low-level protocol control messages and commands.

```
red5-server-common...\rtmp\RTMPUtils.java
161⊖
          * Encodes header size marker and channel id into header marker.
162
            @param out output buffer
163
164
165
            @param headerSize
                                       Header size marker
            Oparam channelId
166
                                       Channel used
167
         public static void encodeHeaderByte(IoBuffer out, byte headerSize, int channelId) {
168⊖
169
             if (channelId <= 63) {</pre>
170
                 out.put((byte) ((headerSize << 6) + channelId));
171
             } else if (channelId <= 320) {</pre>
172
                 out.put((byte) (headerSize << 6));
173
                 out.put((byte) (channelId - 64));
174
             } else {
                 out.put((byte) ((headerSize << 6) | 1));
175
                 channelId -= 64:
176
177
                 out.put((byte) (channelId & 0xff));
178
                 out.put((byte) (channelId >> 8));
179
                                                                                                            ONNURINET
180
```

> RTMP Packet Header - Chunk Message Header



The **Chunk Message Header** contains meta-data information such as the message size (measured in bytes), the **Timestamp Delta** and **Message Type**. This last value is a single byte and defines whether the packet is an audio, video, command or "low level" RTMP packet such as an RTMP Ping.

\*\*red5-server-common...\codec\RTMPProtocolEncoder.java

```
private byte getHeaderType(final Header header, final Header lastHeader) {
327⊖
328
             if (lastHeader == null),{-----
                 return HEADER_NEW; __OxOO____
329
330
331
             final Integer lastFullTs = ((RTMPConnection) Red5.getConnectionLocal()).getState().getLastFullTimestampWritten(
332
             if (lastFullTs == null) {
333
                 return HEADER NEW;
334
335
             final byte headerType;
             final long diff = RTMPUtils.diffTimestamps(header.getTimer(), lastHeader.getTimer());
336
337
             final long timeSinceFullTs = RTMPUtils.diffTimestamps(header.getTimer(), lastFullTs);
338
             if (header.getStreamId() != lastHeader.getStreamId() || diff < 0 || timeSinceFullTs >= 250) {
339
                 // New header mark if header for another stream
340
                 headerType = HEADER NEW;
341
             } else if (header.getSize() != lastHeader.getSize() || header.getDataType() != lastHeader.getDataType()) {
342
                 // Same source header if last header data type or size differ
343
                 headerType = HEADER SAME SOURCE; \Omega \times \Omega = \Omega
344
             } else if (header.getTimer() != lastHeader.getTimer() + lastHeader.getTimerDelta()) {
345
                 // Timer change marker if there's time gap between header time stamps
346
                 headerType = HEADER TIMER CHANGE;
                                                      _0x02----
347
             } else {
348
                 // Continue encoding
349
                 headerType = HEADER CONTINUE;
350
                                                                                                                               NET
351
             return headerType;
```

> CreateStream - Basic Header

var stream:NetStream = new NetStream(connectionObject);

| Header :12 bytes Hex Code   | ASCII       |
|---|-------------|
| 03 00 0b 68 00 00 19 14 00 00 00 00 02 00 0c 63 72 65 61 74 65 53 74 72 | @IcreateStr |
| 65 61 6D 00 40 00 00 00 00 00 00 05                                     | e a m . @   |

The packet starts with a *Basic Header* of a single byte (0x03) where the 2 most significant bits (b**00**000011) define a chunk header type of 0 while the rest (b00**000011**) define a Chunk Stream ID of 3. The 4 possible values of the header type and their significance are:

- b00 = 12 byte header (full header).
- b01 = 8 bytes like type b00. not including message ID (4 last bytes).
- b10 = 4 bytes Basic Header and timestamp (3 bytes) are included.
- b11 = 1 byte only the Basic Header is included.



> CreateStream - Chunk Message Header

An example is shown below as captured when a flash client executes the following code:

var stream:NetStream = new NetStream(connectionObject);

| Hex Code   | ASCII       |
|--|-------------|
| 01 02 03 04 05 06 07 08 09 10 11 12<br>03 00 0b 68 00 00 19 14 00 00 00 00 02 00 0c 63 72 65 61 74 65 53 74 72 | @IcreateStr |
| 65 61 6D 00 40 00 00 00 00 00 00 05  | e a m . @   |

The next bytes of the RTMP Header are decoded as follows:

- byte #1 (0x03) = Chunk Header Type.
- byte #2-4 (0x000b68) = Timestamp delta.
- byte #5-7 (0x000019) = Packet Length in this case it is 0x000019 = 25 bytes.
- byte #8 (0x14) = Message Type ID 0x14 (20) defines an **AMF0** encoded *command* message.
- byte #9-12 (0x00000000) = Message Stream ID. This (strangely) is in **little-endian** order



CreateStream - Message Type ID

An example is shown below as captured when a flash client executes the following code:

var stream:NetStream = new NetStream(connectionObject);

| Hex Code  | ASCII       |
|---|-------------|
| 03 00 0b 68 00 00 19 14 00 00 00 00 02 00 0c 63 72 65 61 74 65 53 74 72 | @IcreateStr |
| 65 61 6D 00 40 00 00 00 00 00 00 05                                     | e a m . @   |

The Message Type ID byte defines whether the packet contains audio/video data, a remote object or a command. Some possible values for are:

- 0x01 = Set Packet Size Message.
- 0x04 = Ping Message.
- 0x05 = Server Bandwidth
- 0x06 = Client Bandwidth.
- 0x08 = Audio Packet.
- 0x09 = Video Packet.
- 0x11 = An AMF3 type command.
- 0x12 = Invoke (onMetaData info is sent as such).
- 0x14 = An AMF0 type command



CreateStream - Message Type ID

An example is shown below as captured when a flash client executes the following code:

var stream:NetStream = new NetStream(connectionObject);

| Hex Code 01 02 03 04 05 06 07 08 09                                     | ASCII       |
|---|-------------|
| 03 00 0b 68 00 00 19 14 00 00 00 00 02 00 0C 63 72 65 61 74 65 53 74 72 | @IcreateStr |
| 65 61 6D 00 40 00 00 00 00 00 05  | e a m . @   |
| 10 11 12  |             |

:double-precision floating point (8 bytes)

• Following the header, **0x02** denotes a **string** of size 0x000C and values 0x63 0x72 ... 0x6D ("createStream" command). Following that we have a **0x00** (number) which is the transaction id of value 2.0. The last byte is **0x05** (null) which means there are no arguments.



# ➤ Invoke Message Structure (0x14, 0x11)

Some of the message types shown above, such as Ping and Set Client/Server Bandwidth, are considered low level RTMP protocol messages which do not use the AMF encoding format. Command messages on the other hand, whether AMF0 (Message Type of 0x14) or AMF3 (0x11), use the format and have the general form shown below:

```
(String) <Command Name>
(Number) <Transaction Id>
(Mixed) <Argument> ex. Null, String, Object: {key1:value1, key2:value2 ... }
```

The transaction id is used for commands that can have a reply. The value can be either a string like in the example above or one or more objects, each composed of a set of key/value pairs where the keys are always encoded as strings while the values can be any AMF data type, including complex types like arrays.



➤ Ping Message Structure (0x04)

Ping messages are not AMF encoded. They start with a stream Id of **0x02** which implies a full (type 0) header and have a message type of 0x04. The header is followed by 6 bytes which are interpreted as such:

- #0-1 Ping Type.
- #2-3 Second Parameter (this has meaning in specific Ping Types)
- #4-5 Third Parameter (same)

The first two bytes of the message body define the Ping Type which can apparently take 6 possible values.

- Type 0 Clear Stream: Sent when the connection is established and carries no further data
- Type 1 Clear the Buffer.
- Type 3 The client's buffer time. The third parameter holds the value in millisecond.
- Type 4 Reset a stream.
- Type 6 Ping the client from server. The second parameter is the current time.
- Type 7 Pong reply from client. The second parameter is the time when the client receives the Ping.

*Pong* is the name for a reply to a Ping with the values used as seen above.



# > ServerBw/ClientBw Message Structure (0x05, 0x06)

This relates to messages that have to do with the client up-stream and server down-stream bit-rate. The body is composed of 4 bytes showing the bandwidth value with a possible extension of one byte which sets the Limit Type. This can have **one of 3 possible values** which can be: **hard, soft or dynamic** (either soft or hard).



# > Set Chunk Size (0x01)

The value received in the 4 bytes of the body. A default value of 128 bytes exists and the message is sent only when a change is wanted



# > AMF0 - data types

The format specifies the various **data types** that can be used to encode data. Adobe states that AMF is mainly used to represent object graphs that include named properties in the form of key-value pairs, where the keys are encoded as strings and the values can be of any data type such as strings or numbers as well as arrays and other objects. XML is supported as a native type. Each type is denoted by a single byte preceding the actual data. The values of that byte are as below (for AMF0):

- Number 0x00 (Encoded as IEEE 64-bit double-precision floating point number)
- Boolean 0x01 (Encoded as a single byte of value 0x00 or 0x01)
- **String 0x02** (16-bit integer string length with UTF-8 string)
- Object 0x03 (Set of key/value pairs)
- Null 0x05
- ECMA Array 0x08 (32-bit entry count)
- Object End 0x09 (preceded by an empty 16-bit string length)
- Strict Array 0x0a (32-bit entry count)
- Date 0x0b (Encoded as IEEE 64-bit <u>double-precision floating point</u> number with 16-bit integer timezone offset)
- Long String 0x0c (32-bit integer string length with UTF-8 string)
- XML Document 0x0f (32-bit integer string length with UTF-8 string)
- Typed Object 0x10 (16-bit integer name length with UTF-8 name, followed by entries)
- Switch to AMF3 0x11



## > AMF0 - objects

**AMF objects** begin with a **(0x03)** followed by a set of key-value pairs and end with a **(0x09)** as value (preceded by 0x00 0x00 as empty key entry). Keys are encoded as strings with the (0x02) 'type-definition' byte being implied (not included in the message). Values can be of any type including other objects and whole object graphs can be serialized in this way. Both object keys and strings are preceded by **two bytes** denoting their **length** in number of bytes. This means that **strings** are preceded by **a total of three bytes which includes the 0x02 type byte**. Null types only contain their type-definition (0x05). **Numbers** are encoded as <u>double-precision floating point</u> and are composed of **eight bytes**.



> example - AMF0

As an example, when encoding the object below in actionscript 3 code.

```
var person:Object = {name:'Mike', age:'30', alias:'Mike'};
var stream:ByteArray = new ByteArray();
stream.objectEncoding = ObjectEncoding.AMF0; // ByteArray defaults to AMF3
stream.writeObject(person);
```

The data held in the ByteArray is:

|    | Hex code |      |   |   |    |    |    |    |    |    |    |    |    |    |    | ASCII |    |    |    |    |   |   |  |  |  |  |  |  |   |   |   |   |   |  |  |
|----|----------|------|---|---|----|----|----|----|----|----|----|----|----|----|----|-------|----|----|----|----|---|---|--|--|--|--|--|--|---|---|---|---|---|--|--|
|    |          |      |   |   |    |    |    |    |    |    |    |    |    |    |    |       |    |    | 65 |    |   |   |  |  |  |  |  |  |   |   |   |   |   |  |  |
| 00 | 4(       | ) 3e | 0 | 0 | 00 | 00 | 00 | 00 | 00 | 00 | 05 | 61 | 6с | 69 | 61 | 73    | 02 | 00 | 04 | ١. | @ | > |  |  |  |  |  |  | a | 1 | i | a | 3 |  |  |
|    |          | 6 E  |   |   |    |    |    |    |    |    |    |    |    |    |    |       |    |    |    |    |   |   |  |  |  |  |  |  |   |   |   |   |   |  |  |

legend: object start/end object keys object values ecma\_array

:length
:double-precision floating point (8 bytes)



> example (2) - AMF0

```
(command) "_result"
(transaction id) 1
(value)
[1] { fmsVer: "FMS/3,5,5,2004"
     capabilities: 31.0
     mode: 1.0 },
[2] { level: "status",
     code: "NetConnection.Connect.Success",
     description: "Connection succeeded",
     data: (array) {
```

The AMF message starts with a **0x03** which denotes an RTMP packet with Header Type of 0, so 12 bytes are expected to follow. It is of Message Type 0x14, which denotes a command in the form of a string of value "\_result" and two serialized objects as arguments. The message can be decoded as follows:

| ()) (                    |    |    |           |    |    |    |    |    |    |      |    |    |    |    |               |    |    |    |   |   |     |   |     |     |   |            |     |   |     |     |     |   |   |
|--------------------------|----|----|-----------|----|----|----|----|----|----|------|----|----|----|----|---------------|----|----|----|---|---|-----|---|-----|-----|---|------------|-----|---|-----|-----|-----|---|---|
| version: "3,5,5,2004" }, |    |    |           |    |    |    |    |    | He | к со | de |    |    |    |               |    |    |    |   |   |     |   |     |     | - | ASC        | 11  |   |     |     |     |   |   |
| entld: 1584259571.0,     | 03 | 00 | 00        | 00 | 00 | 01 | 05 | 14 | 00 | 00   | 00 | 00 | 02 | 00 | 07            | 5F | 72 | 65 |   |   |     |   |     |     |   |            |     |   |     |     |     |   |   |
| , ,                      | 73 | 75 | 6C        | 74 | 00 | 3F | F0 | 00 | 00 | 00   | 00 | 00 | 00 | 03 | 00            | 06 | 66 | 6D |   |   |     |   |     |     |   |            |     |   |     |     |     | e |   |
| jectEncoding: 3.0 }      | 73 | 56 | 65        | 72 | 02 | 00 | 0E | 46 | 4D | 53   | 2F | 33 | 2C | 35 | 2C            | 35 | 2C | 32 |   |   |     |   |     |     |   |            |     |   |     |     |     | 3 |   |
|                          | 30 | 30 | 34        | 00 | 0C | 63 | 61 | 70 | 61 | 62   | 69 | 6C | 69 | 74 | 69            | 65 | 73 | 00 |   |   |     |   |     |     |   |            |     |   |     |     |     | 0 |   |
|                          | 40 | 3F | nn        | 00 | nn | 00 | nn | nn | 00 | 0.4  | 6D | 6F | 64 | 65 | 00            | ЗF | FΩ | 00 | - | • | са  | p | a l | o i | 1 | i t        | i   | e | 3   | - 0 |     | • |   |
|                          |    | 00 |           |    |    |    |    |    |    |      | ,  |    |    |    | $\overline{}$ |    |    |    | • |   |     | ٠ | . 1 | n o | d | е .        | . ? | ٠ | •   |     | •   | • |   |
|                          | '  | 73 |           |    |    | 1  |    | _  | _  |      |    |    |    |    |               |    |    |    | • | • |     | ٠ |     | l e | ٧ | e ]        | L.  | ٠ | - : | s t | : a | t | u |
|                          |    | 43 |           |    |    |    |    |    |    |      |    |    |    |    |               |    |    |    | s |   | . с | 0 | d ( | • • |   | . 1        | 1 e | t | C ( | 0 I | n   | e | c |
|                          |    |    |           |    |    |    |    |    |    |      |    |    |    |    |               |    |    |    | t | i | o n |   | C d | n   | n | e d        | : t |   | S 1 | u c | : с | e | 3 |
|                          |    | 2E |           |    |    |    |    |    |    |      |    |    |    |    |               |    |    |    | 3 |   | . d | e | 3 ( | r   | i | p t        | i   | 0 | n   |     |     | C | 0 |
|                          |    | 69 |           |    |    |    |    |    |    |      |    |    |    |    |               |    |    |    | n | n | e c | t | i ( | o n |   | <b>3</b> 1 | ıc  | С | е ( | e d | l e | d |   |
|                          | 73 | 75 | 63        | 63 | 65 | 65 | 64 | 65 | 64 | 2E   | 00 | 04 | 64 | 61 | 74            | 61 | 08 | 00 |   |   | d a | + | a   |     |   |            |     |   | T   | e 7 |     | i | _ |
|                          | 00 | 00 | 01        | 00 | 07 | 76 | 65 | 72 | 73 | 69   | 6F | 6E | 02 | 00 | 0A            | 33 | 2C | 35 |   |   |     |   |     |     |   |            |     |   |     |     |     |   |   |
|                          | 2C | 35 | 2C        | 32 | 30 | 30 | 34 | 00 | 00 | 09   | 00 | 08 | 63 | 6C | 69            | 65 | 6E | 74 |   |   |     |   |     |     |   |            |     |   |     |     |     |   |   |
|                          | 69 | 64 | 00        | 41 | D7 | 9в | 78 | 7c | C0 | 00   | 00 | 00 | 0E | 6F | 62            | 6A | 65 | 63 |   |   |     |   |     |     |   |            |     |   |     |     |     | • |   |
|                          | 74 | 45 | 6E        | 63 | 6F | 64 | 69 | 6E | 67 | 00   | 40 | 08 | 00 | 00 | 00            | 00 | 00 | 00 | 0 | b | j e | С | t I | Ξn  | С | 0 0        | li  | n | g   | . @ | -   | • |   |
| :_İ :ECMA Array          | 00 | 00 | <u>09</u> |    |    |    |    |    |    |      |    |    |    |    |               |    |    |    | • | • | • • | • | •   | •   |   |            |     |   |     |     |     |   |   |
|                          |    |    |           |    |    |    |    |    |    |      |    |    |    |    |               |    |    |    |   |   |     |   |     |     |   |            |     |   |     |     |     |   |   |

:ECMA Array

clientId: 1584259571.0. objectEncoding: 3.0 }


:length

legend: object start/end object keys object values ecma array

:double-precision floating point (8 bytes)




➤ Red5: Encode string 과정 sequence diagram





#### > Red5: AMF Output class diagram




#### Red5-io/src/main/java/org/red5/io/amf/Output.java

```
486⊖
          public void writeString(String string) {
              final byte[] encoded = encodeString(string);
 487
              final int len = encoded.length;
3488
              if (len < AMF.LONG_STRING_LENGTH) {</pre>
 489
                  buf.put(AMF.TYPE STRING);
 490
                  buf.putShort((short) len);
 491
 492
              } else {
                                               Jength - .
                  buf.put(AMF.TYPE_LONG_STRING);
 493
                  buf.putInt(len);
 494
 495
              buf.put(encoded);
 496
                                              Encoded str.
 497
         public void writeNumber(Number num) {------
 286⊖
              buf.put(AMF.TYPE_NUMBER);
 287
                                                _0x00
              buf.putDouble(num.doubleValue());
 288
                                                double-precision
 289
                                                floating point.
```



#### > Red5: AMF3 Output class diagram

#### Red5-io/src/main/java/org/red5/io/amf3/Output.java



```
public void writeNumber(Number num) {
L88
L89
            writeAMF3();
L90
            if (num.longValue() < AMF3.MIN INTEGER VALUE || num.longValue() > AMF3.MAX INTEGER VALUE) {
L91
                // Out of range for integer encoding
192
                buf.put(AMF3.TYPE_NUMBER); 
                buf.putDouble(num.doubleValue());
L93
            } else if (num instanceof Long | num instanceof Integer | num instanceof Short | num instanceof Byte) {
L94
                buf.put(AMF3.TYPE INTEGER);
                                                    double-precision
L95
L96
                putInteger(num.longValue());
                                                    floating point.
L97
            } else {
                buf.put(AMF3.TYPE NUMBER);
L98
L99
                buf.putDouble(num.doubleValue());
200
201
```



- ➤ 참고 자료
- rtmp spec.pdf
   <a href="https://www.adobe.com/content/dam/Adobe/en/devnet/rtmp/pdf/rtmp\_specification\_1.0.pdf">https://www.adobe.com/content/dam/Adobe/en/devnet/rtmp/pdf/rtmp\_specification\_1.0.pdf</a>
- AMF0 spec.pdf
   <a href="http://download.macromedia.com/pub/labs/amf/amf0">http://download.macromedia.com/pub/labs/amf/amf0</a> spec 121207.pdf
- AMF3 spec.pdf
   <a href="http://download.macromedia.com/pub/labs/amf/amf3\_spec\_121207.pdf">http://download.macromedia.com/pub/labs/amf/amf3\_spec\_121207.pdf</a>
- Red5 in github
   <a href="https://github.com/Red5">https://github.com/Red5</a>
- Action Message Format
   <a href="https://en.wikipedia.org/wiki/Action\_Message\_Format">https://en.wikipedia.org/wiki/Action\_Message\_Format</a>



# Thank You!